



1. Asenna osa 8 kattokoukkuun.
2. Kytke pistotulppa tai sähköjohdot.
3. Asenna polttimot, 3 kpl. (E27)
4. Asenna osa 6 kattoa vasten ja kiristä mutterilla, osa 9.
5. Ruuvaa tanko (osa 5) mutteriin (osa 9).
6. Asenna musta mutteri, osa 4 tankoon.
7. Nosta valaisimen varjostin (osa 1) mustaa mutteria (osa 4) vasten.
8. Asenna valkoinen mutteri, osa 2 tangon, osa 5 pätyyn.
9. Paina päätytulppa, osa 3 valkoisen mutterin, osa 2 reikään.

1. Mount the part 8 to your ceiling hook.
2. Connect the electric end plug or the electric cables.
3. Mount the light bulbs, 3 pcs. (E27)
4. Mount the part 6 against the ceiling and tighten it with the nut, part 9.
5. Screw the bar (part 5) to the nut (part 9).
6. Screw the black nut, part 4 on the bar.
7. Lift the lampshade, part 1 against the black nut, part 4.
8. Screw the white nut, part 2 on the end of the bar, part 5.
9. Press the end cup, part 3 in the hole of the white nut, part 2.

DETAIL A
SCALE 1 : 1

DETAIL B
SCALE 1 : 1

Rev	Muutos / Change	Pvm / Date	Suun. / Des'd
-		27.1.2014	PPe

	Massa / Mass 2.82 kg	Asiakas tai Projekti / Customer or Project Keraplast Oy	Suunnittelija / Designed By PPe	Pvm / Date 20.01.2014
	Mittakaava / Scale A2 1:2	Tilaus- tai Työnnumero / Order or Work Number Umbrella	Tehdään kpl / Quantity manufactured 1 / 1	Sheet/Sheets 1 / 1
KERAPLAST INTERIOR Käkeläntie 41 FIN-16300 Orimattila Tel. +3583 544 3100 Fax. +3583 544 3160			Nimitys / Description Asennusohje Installation instruction 19843	
			Piirustusnumero / Drawing Number 19843	Rev -